



# FAA San Diego Call Center

## *Cisco vXML Setup*

**Prepared For:  
FAA San Diego**

**Prepared By:  
AT&T**

**Version 1.0  
September 6, 2008**



# Table of Contents

|                                     |            |
|-------------------------------------|------------|
| <b>TABLE OF CONTENTS</b> .....      | <b>II</b>  |
| <b>EXECUTIVE SUMMARY</b> .....      | <b>III</b> |
| <b>REQUIREMENTS</b> .....           | <b>IV</b>  |
| <b>CONFIGURATION OVERVIEW</b> ..... | <b>V</b>   |



# Executive Summary

The purpose of this document is to provide an overview of the vXML configuration used in the IPCC environment. This guide will address the areas of setup based on best practices provided from Cisco Systems with any modifications required for equipment deployment in the **FAA San Diego** environment.

With new hardware, even with the same part number, you may have revisions of the accompanying software that may affect this guide. Please contact AT&T if this happens and this document will be updated to reflect these changes.

It is also suggested to contact Cisco or log on to [www.cisco.com](http://www.cisco.com) and find the latest supported versions of the server setup software.

This guide has been designed to be usable by both an experienced IT engineer or one with less experience in the area of server setup. This document was designed to help the engineer through the many choices you have during setup to achieve a designated configuration for Cisco IPCC environment on a Windows Server 2003 operating system.



# Requirements for the Gateway

## 1. System Power

- a. The power supplying the system must be able to support the server's requirements: Rated line voltage 100-127 VAC and 200-240 VAC & Rated input current 10A (100 VAC), 10A (120 VAC), and 5A (200 VAC)
- b. UPS protection is strongly suggested for this server if it will be in production, along with Windows 2003 agents to respond to an outage with a graceful shutdown.

## 2. HVAC & Operating environments

- a. The system should be set up in a cool, dry area for optimal operation. Range of 50° to 95° F (10° to 35° C) at 0 - 3000 feet (0 - 914.4 meters) with an altitude derating of 0.75° C per 1000 ft to 10,000 ft (3048 m)
- b. Cooling should be able to handle a BTU rating of BTU/hr 3390
- c. Maximum altitude 7000 ft (2133 m)

## 3. Input and Output

### a. Network Connection

- i. The Ethernet cable should be connected to an active network connection on a network switch.
- ii. Speed and Duplex **MUST** be set on both the server and switch to match (Not Auto). This deployment has been tested at 100/full and testing is continuing with 1000/full. At the time of this document, the gigabit/full has not been certified.
- iii. Prior to installing the server, you should collect what the IP address, Subnet Mask, Default Gateway, DNS Server, and WINS server will be.
- iv. All TCP/IP ports should be open and accessible to the client devices that they will be supporting; a more granular list is based on what application will be installed on the system.



# Configuration of vXML Defined

The following is a configuration for the vXML – Most default items have been removed to reference

1. `service nagle`
  - a. Nagle is a congestion control algorithm used to reduce the transmission of small packets. It's a bandwidth-saving feature for keystroke-based applications (such as Telnet). While the Cisco IOS turns off Nagle by default, you can enable it with the `service nagle` command.
2. `service linenum`
  - a. This command notifies the user of the router's or switch's async line number used at login. This can come in handy if you're having problems with your VTY line – it reminds you what line you're on. It even works on the console.
3. `service sequence-numbers`
  - a. `service sequence-numbers` You can use the `service sequence-numbers` command to insert sequence numbers into log files. This can be important when log entries are coming really quickly. In fact, they can come so quickly that they appear at the same time.
4. `ip domain name FAASDIPT.com`
  - a. Set the domain name for the system
5. `ip host FAASDCMPUB 10.100.59.31`
  - a. Add the DNS Entries as backup to a DNS Server
6. `multilink bundle-name authenticated`
  - a. You can change the criteria that is selected for naming a multilink bundle if you issue the `multilink bundle`
7. `voice call send-alert`
  - a. To enable the terminating gateway to send an alert message instead of a progress message after it receives a call setup message, use the `voice call send-alert` command in global configuration mode.
8. `voice rtp send-recv`
  - a. To establish a two-way voice path when the Real-Time Transport Protocol (RTP) channel is opened, use the `voice rtp send-recv` command in global configuration mode
9. `voice class codec 100`
  - a. The following example shows configuration for voice class codec 10 with two audio codec preferences and three video codec preferences
10. `service cvp-survivability flash:survivability.tcl`
  - a. `param space english language en`
  - b. `param space english index 0`



- c. paramspace english location flash
  - d. paramspace english prefix en
- 11. service cvperror flash:cvperror.tcl
  - a. paramspace english language en
  - b. paramspace english index 0
  - c. paramspace english location flash
  - d. paramspace english prefix en
- 12. service ringtone flash:ringtone.tcl
  - a. paramspace english language en
  - b. paramspace english index 0
  - c. paramspace english location flash
  - d. paramspace english prefix en
- 13. service handoff flash:handoff.tcl
  - a. paramspace english language en
  - b. paramspace english index 0
  - c. paramspace english location flash:
  - d. paramspace english prefix en
- 14. archive
  - a. To enter archive configuration mode, use the archive command in global configuration mode.
- 15. log config
  - a. Enters configuration change logger configuration mode.
- 16. hidekeys
  - a. Suppresses the display of password information in configuration log files. Note Enabling the hidekeys command increases security by preventing password information from being displayed in configuration log files.
- 17. MRCP
  - a. mrcp client timeout connect 5
  - b. mrcp client timeout message 5
  - c. mrcp client rtpsetup enable
- 18. vxml tree memory 15000
  - a.
- 19. http
  - a. http client cache memory pool 35000
  - b. http client cache memory file 600
  - c. http client cache refresh 86400
  - d. http client response timeout 1



20. h323-gateway

- a. h323-gateway voip interface
- b. h323-gateway voip id FAASDUCCZONE1 ipaddr 10.100.99.30 1719 priority 120
- c. h323-gateway voip id FAASDUCCZONE2 ipaddr 10.200.0.20 1719
- d. h323-gateway voip h323-id FAASDUCCVXML05
- e. h323-gateway voip tech-prefix 2#
- f. h323-gateway voip bind srcaddr 10.10.99.50

21. ss7

- a. ss7 mtp2-variant Bellcore 0
- b. ss7 mtp2-variant Bellcore 1
- c. ss7 mtp2-variant Bellcore 2
- d. ss7 mtp2-variant Bellcore 3



# Full Gateway Configuration

The following is a full configuration and has not been finalized at the time of document.

```
FAASDUCCVXML05#sh run
Building configuration...

Current configuration : 4024 bytes
!
! Last configuration change at 19:49:14 UTC Mon Aug 25 2008
! NVRAM config last updated at 19:52:22 UTC Mon Aug 25 2008
!
version 12.4
service nagle
service timestamps debug datetime msec localtime
service timestamps log datetime localtime show-timezone
service password-encryption
service linenumbers
service sequence-numbers
no service dhcp
!
hostname FAASDUCCVXML05
!
boot-start-marker
boot system flash:c5350-is-mz.124-15.T1.bin
no boot startup-test
boot-end-marker
!
no logging console
enable secret 5 $1$xxxxxxxxxxxxxxxx/OQxxxxIk/
enable password 7 01100F175804
!
resource-pool disable
```





```
no aaa new-model
spe default-firmware spe-firmware-1
!
ip cef
!
multilink bundle-name authenticated
!
voice rtp send-recv
!
voice service voip
  h323
!
voice class codec 100
  codec preference 1 g711ulaw
  codec preference 2 g729br8
  codec preference 3 g729r8
!
application
  service vru-leg flash:bootstrap.tcl
  paramspace english index 0
  paramspace english language en
  paramspace english location flash
  paramspace english prefix en
!
  service new-call flash:bootstrap.vxml
  paramspace english index 0
  paramspace english language en
  paramspace english location flash
  paramspace english prefix en
!
  service handoff flash:handoff.tcl
  paramspace english index 0
  paramspace english language en
  paramspace english location flash:
```



```
    paramspace english prefix en
!
mrCP client timeout connect 5
mrCP client timeout message 5
mrCP client rtpsetup enable
vXML tree memory 15000
http client cache memory pool 35000
http client cache memory file 600
http client cache refresh 86400
http client response timeout 1
!
archive
  log config
  hidekeys
!
interface Loopback0
  description FAASDUCCVXML05 Loopback0
  ip address 10.100.99.50 255.255.255.255
  no ip redirects
  h323-gateway voip interface
  h323-gateway voip id FAASDUCCZONE1 ipaddr 10.100.9.30 1719 priority 120
  h323-gateway voip id FAASDUCCZONE2 ipaddr 10.200.0.20 1719
  h323-gateway voip h323-id FAASDUCCVXML05
  h323-gateway voip tech-prefix 2#
  h323-gateway voip bind srcaddr 10.10.99.50
!
interface GigabitEthernet0/0
  ip address 10.100.59.121 255.255.255.128
  ip access-group 198 in
  no ip unreachableS
  ip route-cache policy
  ip route-cache flow
  ip ospf priority 0
  ip policy route-map nachI-worm
```



```
load-interval 30
duplex full
speed 100
negotiation auto
!
interface GigabitEthernet0/1
no ip address
shutdown
duplex auto
speed auto
negotiation auto
!
interface Serial0/0
no ip address
shutdown
clock rate 2000000
no fair-queue
!
interface Serial0/1
no ip address
shutdown
clock rate 2000000
!
router ospf 100
log-adjacency-changes
network 10.100.99.50 0.0.0.0 area 10.100.28.146
network 10.100.59.0 0.0.0.127 area 10.100.28.146
network 10.100.59.128 0.0.0.127 area 10.100.28.146
maximum-paths 6
!
no ip http server
!
control-plane
!
```



```
dial-peer voice 900 voip
  service vru-leg
  voice-class codec 100
  incoming called-number 10002T
  dtmf-relay rtp-nte h245-signal h245-alphanumeric
  no vad
```

!

```
gateway
```

```
  timer receive-rtp 1200
```

!

```
ss7 mtp2-variant Bellcore 0
```

```
ss7 mtp2-variant Bellcore 1
```

```
ss7 mtp2-variant Bellcore 2
```

```
ss7 mtp2-variant Bellcore 3
```

```
banner motd ^CCC
```

WARNING:

This system is provided for FAA San Diego business purposes by authorized users

only. Users of company resources, including computers, communications equipment, and associated services provided by these resources (e.g., internet, electronic mail, facsimile, voice mail, hardcopy) are to be used for company business purposes only. The company reserves the right to monitor usage of all auditing purposes and when such action is deemed necessary due to business circumstances. Anyone using this system expressly consents to such monitoring.^C

!

```
line con 0
```

```
  password 7 143xxxxxxxxxxx7874
```

```
  stopbits 1
```

```
line aux 0
```

```
  password 7 12xxxxxxxxxxx1718
```

```
  stopbits 1
```

```
line vty 0 4
```

```
  exec-timeout 120 0
```



```
password 7 052xxxxxxxxxxxx5A49
login
!
scheduler allocate 10000 400
ntp clock-period 17179874
ntp server 10.100.119.84
ntp server 10.100.119.83
end
```

**This Configuration will change as needed**